

Birlea®

Assembly Instructions

Thank you for
purchasing a
Birlea product.

For a chance to win a Love 2 Shop voucher simply post a picture of your new product on your preferred social channels tagging Birlea Furniture and using the hashtag **#ShareYourStyle** and **#Birlea**. One winner will be selected at random each month.

To view our full terms and conditions please visit www.birlea.com

Are you happy with your purchase?

Yes: That's great, we would love to hear more from you. Please leave us a review on our social media channels or Trustpilot. Your feedback will be greatly appreciated.

No: If for any reason there is something missing, indifferent or incorrect with your order, please contact the retailer you purchased the item from. We will work with the retailer to resolve your issue as quickly as possible.



ASSEMBLY INSTRUCTIONS **CROXLEY 1 DRAWER RATTAN BEDSIDE**

IMPORTANT : READ THESE INSTRUCTIONS CAREFULLY BEFORE ATTEMPTING TO ASSEMBLE OR USE YOUR CROXLEY 1 DRAWER RATTAN BEDSIDE.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

Keep small children and pets away during assembly as there are small parts.

DO NOT USE ANY POWER TOOLS AS THEY MAY DAMAGE THE FURNITURE AND WILL INVALIDATE ANY CLAIM

ASSEMBLY:

Assembly should be carried out with this item laying flat, not standing upright.

Assemble on a soft, clean surface to prevent damages.

To erase the numbers printed on the pieces, use the rubber inside the accessories pack.

HEALTH & SAFETY:

DO NOT use this product if any parts are missing, damaged or worn.

DO NOT use this product unless all fixings are secured.

Always use on a level, even surface.


CARE & MAINTENANCE:



Periodically check all screws & fixings to ensure they are secure.

DO NOT push this product as this will cause damage.

Always lift this product with two people to repositions.

Keep any sharp objects away from this product.






Birlea®

Parts List				Hardware List		
Part	Description	Box	Qty	Part	Description	Qty
1	Side Panel(Left)	1	1	A	CAM BOL 	8
2	Side Panel(Right)	1	1	B	CAM LOCK 	8
3	Top Panel	1	1	C	Wooden Dowel 	8
4	Wooden Leg	1	4	D	Threaded Bolt 	4
5	Bottom Panel	1	1	E	Leg Bracket 	4
6	Back Panel	1	1	F	Dorned head Screw 	21
7	Drawer Side(Left)	1	1	G	Flathead Screw 	10
8	Drawer Side(Right)	1	1	H	Handle+ Screw 	1
9	Drawer Back	1	1	I	Plastic Wedge + Screw 	4
10	Drawer Front	1	1	J	Foot pad 	4
11	Drawer Bottom	1	1	K	Sticker 	4
** You will need a small mallet and a screwdriver for assembly. ** Some screws and wooden dowel may remain. ** Note : To secure the item to the wall.				L	Washer 	1
				M	Safety strap 	1
				N	Threaded Bolt 	4
				O	Allen key 	1
				DL	Drawer Runner 	1
				DR	Drawer Runner 	1
				CL	Drawer Runner 	1
				CR	Drawer Runner 	1

STEP 1: Attach drawer back panel(9) to drawer side panels(7) and (8) using threaded bolts D. Then slide the bottom panel(11) into the groove;

Dx4






STEP 2: Screw the cambolts (A) into the drawer front (10), then slide the drawer front (10) onto the drawer box. Insert the cam locks (B) into the holes in the side panels (7) and (8) and rotate to lock onto the cambolts. Cover the cams with the stickers (K). Attach the drawer handle (H) with the screw provided.

Ax4

Bx4


Kx4

Hx1




Birlea®

STEP 3: Attach the drawer runners DR and DL to the base of the drawer box using the flatheaded screws G



STEP 4: Attach the drawer runners (CL) and (CR) to the side panels (1) and (2) using the flatheaded screws (G)






STEP 5: Screw the cambolts (A) and push the dowels (C) into the top panel (3)

then slide the side panels (1) and (2) onto the top panel (3)



Insert the cam locks (B) into the holes in panels (1) and (2) and rotate with a cross-headed screwdriver to secure.

Ax4
Bx4
Cx4

**STEP 6: Slide the back panel (6) into the groove in the side and top panels**

Push dowels (C) into the bottom of the side panels (1) and (2); then attach the bottom panel (5) using threaded bolts (N)


Cx4
Nx4
Ox1



Birlea®

STEP 7: Attach the leg brackets (E) to the base panel (5) using screws (F)


Ex4
Fx20



Step 8: Screw the legs (4) into the leg brackets (E) then attach the pads (J)

Insert the plastic wedges (I) into the back panel groove in the corners and secure with the supplied screws


Jx4
Ix4



Birlea®

Step 9: Secure the safety strap (M) to the back of the table with the washer (L) and screw (F)

Lx1
Fx1
Mx1



PLEASE NOTE that wall fixings are not supplied as different wall materials require different fixing devices. You must use fixings devices suitable for the type of wall you intend to mount product to. Ensure the head of any screw used has a diameter greater than the mounting hole and the fixing is safe and secure before use.

Birlea Furniture advise you use the wall straps provided to further enhance the safety of this product.

Additional Information:

- For complete product information, images and dimension diagrams please visit the website www.birlea.com
- If you have any issues with your item please contact the retailer directly you purchased it from who will be able to resolve any issues with Birlea.
- Why don't you send us photos of your assembled furniture to info@birlea.com to be shared in our #birleahome feature on Instagram.

Birlea®