

Assembly Instructions

Thank you for purchasing a Birlea product.

For a chance to win a Love 2 Shop voucher aimply post a picture of your new product on your preferred social channels tagging Birlea Furniture and using the hashtag #Share Your Style and #Birlea. One winner will be selected at random each month.

Some and Morrow and complete private colorate certains, associated association com-

Are you happy with your purchase?

Yes: That's great, we would love to hear more from you. Please leave us a review on our social media channels or Trustpilot. Your feedback will be greatly appreciated.

No: If for any reason there is something missing, indifferent or incorrect with your order, please contact the retailer you purchased the item from. We will work with the retailer to resolve your issue as quickly as possible.





ASSEMBLY INSTRUCTION

90CM PRINCESS BED

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

Assembly to be carried out by a competent adult only.

During assembly children should be kept away from the product due to the possible risk of injury.

Do not use the furniture if any part is broken, tom or missing and use only spare parts approved by the manufacturer.

Assemble the furniture on a soft level surface to avoid damaging the product or your floor.

We recommend furniture be assembled near where they will be placed, to avoid moving the product unnecessarily once assembled.

If there is a need to move the furniture, please remove all loose items and have extra hands to help lift the furniture to the desired location. Dragging the furniture will damage both the furniture and the floor.

Ensure that fingers and legs are clear of all adjustments when adjusting this product.

Regularly check and re-tighten (if necessary) all bolts on furniture that you have assembled yourself.

This product is suitable for children in the age range 5-12 years.


Care and Maintenance of your Furniture

Avoid placing hot items directly onto the surface unless using a thick insulation material such as placemats or coasters. Heat may lead to discolouration or other damage to the surface of the product.

Use a soft cloth that has been dampened in water to clean the surface of this product. Do not use abrasive cleaners, furniture wax or polish on the surface of this product, as it may damage the surface.

CAUTION: FREQUENT EXPOSURE TO DIRECT SUNLIGHT OR SIMILAR SOURCES MAY CAUSE THE SURFACE TO DISCOLOUR OR FADE.






Parts List									
PART	DESCRIPTION	CITY	SOX	PART	DESCIRPTION	LOTY.	50%		
	Headbsand		E 300	8	Left Side Panel				
2	Flight Side Partel		3	6	Floht Side Panel		T 1		
-3	Left Side Panel			=7 =1	Foutboard		- 11		
4	Support Late	2		- 5	Bed Start	177			


HARDWARE (IN BOX 1)


Α	© посин	MSEESTIN)	12
В	Q	Ø16x10mm	14
C	() —	Moxionin	4
D	E-20	MEXADITIO	2


	600	MEXISTOOT	2
E	8	213x12mm	2
G	-	MEXIS Sorr	4


^{**}You will need a Phillips head screwdriver and a Flat head screwdriver (not provided)











↑ WARNING!

Do NOT place this child's bed near heat sources, windows and other furniture

Do NOT use the child's bed if any part is broken, torn or missing and use only spare parts approved by the manufacturer.

Use mattress which is 190cm long and 90cm wide on the bed.

The child's bed conforms to BS8509:2008 + A1: 2011.

Additional Information:

- For complete product information, images and dimension diagrams please visit the website www.birlea.com
- If you have any issues with your item please contact the retailer directly you purchased it from who will be able to resolve any issues with Birlea.
- Why don't you send us photos of your assembled furniture to info@birlea.com to be shared in our #birleahome feature on Instagram.

