Birlea

Assembly Instructions

Thank you for purchasing a Birlea product

For a chance to win a Love2Shop voucher simply post a picture of your new product on your preferred social channels tagging Birlea Furniture. One winner will be selected at random each month.

*Terms & conditions may apply

Are you happy with your purchase?

Yes: That's great, we would love to hear more from you. Please leave us a review on our Trustpilot link on the QR code here. Your feedback will be greatly appreciated.



No: If for any reason there is something missing, indifferent or incorrect with your order, please contact the retailer that you purchased your item from.

Please note that this items build time is around 60 min.





Code: S000238 0 0 0 6 Left footboard post (40 x 5.2cm) 0 0 0 7 Right footboard post (40 x 5.2cm) 8 Slat x 24 (68.2 x 6.5cm) 1 Headboard panel (134 x 57.4cm) 9 Support leg (26.4 x 5.2cm) 2 Footboard panel (134 x 11.2cm) 12 Joint centre rail 3 Side rail x 4 (95 x 11.2cm) 10 Support side rail x 2 (20 x 6.5cm) (32 x 6.5cm)

Support leg x 2 (28.3 x 6.5cm)

13 Hardware Kit x 1


		H	ARDWA	ARE LIS	ST .		
Part	Item		Qty	Part	Item		Qty
A	30mm dowel		10	K	100mm Bolt 0		4
В	40mm dowel		12	•	Half moon nut		4
G	16mm Screw		16	M	Coupling screw	0	4
D	30mm Screw	(3)—mmm»	52	0	Washer	0	4
3	22mm Bolt		4	0	Metal bracket		2
G	32mm Bolt		2	Ð	Metal bracket		2
G	Nut		2	Q	Allen key		1
(1)	50mm Bolt	<u> </u>	3	R	Spacer		2
0	90mm Bolt	WINIMAN	6	6	Plastic hole plugs		4

You will need a screwdriver, small mallet and M11 spanner (not provided).

4 Centre rail x 2 (95.2 x 6.5cm)


Headboard post x 2 (85 x 5.2cm)

0 0 0



Step 1: Insert hardware part A into the joint centre rail (12) using a small mallet (not provided). Join the support leg (9) to the joint centre rail (12) using hardware H and Q.

DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Vendor: S000238


Page 3 of 8

Step 2: Join both centre rails (4) using the joint centre rail (12) and hardware D and a screwdriver (not provided). Please note that the side with 1 hole must be turned outside.

DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Step 3: Join the support legs (11) to the centre rail using hardware H and Q. **DO NOT use any power tools as this may damage the frame and will invalidate any claim.**




Step 4: Insert hardware part B to the side rails (3) using a small mallet (not provided).

Vendor: S000238

Step 5: Insert the dowels B into both siderails as per the drawing. Please note that the support for the slats must be pointing up and the holes must be pointing outside.





Step 6: Join the two rails (3) and attach the support leg (10) using hardware E, M, N (spanner not provided). **DO NOT use any power tools as this may damage the frame and will invalidate any claim.**




Step 7: Attach metal bracket P to the joint of the siderails using hardware C and a screwdriver (not provided) to fix them, this is for extra support.

DO NOT use any power tools as this may damage the frame and will invalidate any claim.







Step 8: Insert hardware part A to the headend panel (1) and footend panel (2) using a small mallet (not provided).



Step 9: Attach the headend post (5) to the headend panel (1) using hardware parts J and Q. Vendor: S000238 **DO NOT use any power tools as this may damage the frame and will invalidate any claim.**




Step 10: Attach the left footend post (6) and right footend post (7) to the footend panel (2) using hardware parts J and Q. **DO NOT use any power tools as this may damage the frame and will invalidate any claim.**




Step 11: Fix hardware part O to the headend panel (1) and footend panel (2) using hardware part C and a screwdriver (not provided).

DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Step 12: Attach the side rails to the headend posts at the same time using hardware parts K, L and Q. **DO NOT use any power tools as this may damage the frame and will invalidate any claim.**




Step 13: Fix the centre rail (4) using hardware parts F and G and a spanner (not provided). Vendor: S000238 Insert hardware part S to the side rails.

DO NOT use any power tools as this may damage the frame and will invalidate any claim.



Step 14: Fix slats (8) to the side rails and centre rail using hardware parts R and D with a screwdriver (not provided). Make sure to start from the ends and work towards the middle.

DO NOT use any power tools as this may damage the frame and will invalidate any claim



Additional Information:

- For complete product information, images and dimension diagrams please visit the website www.birlea.com
- If you have any issues with your item please contact the retailer directly you purchased it from who will be able to resolve any issues with Birlea.
- Why don't you send us photos of your assembled furniture to info@birlea.com to be shared in our #birleahome feature on Instagram.

